




OPERATOR'S MANUAL

SM-BM-21S

BEVELING MACHINE



15335 E. Fremont Drive, Centennial, CO 80112

1- 87STEELMAX, FAX 303 - 690 - 9172

www.steelmax.com sales@steelmax.com

Contents

1. GENERAL INFORMATION	3
1.1. Application	3
1.2. Technical data.....	3
1.3. Dimensions	4
1.4. Design	5
1.5. Equipment included	6
2. SAFETY PRECAUTIONS.....	7
3. STARTUP AND OPERATION	9
3.1. Preparing	9
3.1.1. Adjusting the bevel angle and width.....	9
3.1.2. Using the cutting fluid	10
3.2. Adapting for 150–300 mm pipes	11
3.3. Adapting for 300–600 mm pipes (option).....	14
3.4. Operating	15
3.5. Replacing the cutting inserts	17
3.6. Replacing the milling head	18
4. SPARE AND WEARING PARTS.....	19
5. ACCESSORIES	20
5.1. Guide for 300–600 mm pipes	20
5.2. Cutting tools	20
6. WIRING DIAGRAM	21
7. EXPLODED DRAWINGS AND PARTS LIST.....	22
8. DECLARATION OF CONFORMITY	26
9. WARRANTY CARD.....	27

1. GENERAL INFORMATION

1.1. Application

The BM-21S is a beveling machine designed to bevel stainless steel. The machine can bevel plates, as well as pipes with outer diameters of 150–300 mm (6–12"), at an angle of 0–60° and with the bevel width of up to 21 mm (13/16"). Also, the machine contains dampers to reduce vibrations.

When equipped with an optional guide, the machine can bevel pipes with outer diameters of 300–600 mm (12–24").

1.2. Technical data

Voltage	1~ 220–240 V, 50–60 Hz 1~ 110–120 V, 50–60 Hz
Power	1600 W (for 50 Hz) 1800 W (for 60 Hz)
Rotational speed	1360–1630 rpm (at 230 V) 1300–1560 rpm (at 115 V)
Protection level	IP 20
Protection class	I
Milling speed	270 m/min (900 ft/min, for 50 Hz) 320 m/min (1050 ft/min, for 60 Hz)
Maximum bevel width (<i>b</i>)	21 mm (13/16", Fig. 1)
Bevel angle (β)	0–60° (Fig. 1)
Weight	23 kg (51 lbs)





Fig. 1. Bevel dimensions; maximum bevel width depending on the angle

1.3. Dimensions



1.4. Design





Fig. 2. View of the machine and the control panel

1.5. Equipment included



1	Beveling machine	1 unit
2	Cutting insert	10 units
3	Metal box	1 unit
4	8 mm hex wrench	1 unit
5	6 mm hex wrench	1 unit
6	4 mm hex wrench	1 unit
7	12 mm flat wrench	1 unit
8	T15P torx screwdriver	1 unit
9	Oil for stainless steel	1 unit
10	Grease for screws	1 unit
—	Operator's Manual	1 unit

2. SAFETY PRECAUTIONS

1. Before use, read this Operator's Manual and complete a training in occupational safety and health.
2. Use only in applications specified in this Operator's Manual.
3. Make sure that the machine has all parts and they are genuine and not damaged.
4. Make sure that the specifications of the power source are the same as those specified on the rating plate.
5. Connect the machine to a correctly grounded power source.
6. Do not pull the cord. This can cause damage and electric shock.
7. Keep untrained bystanders away from the machine.
8. Before each use, ensure the correct condition of the machine, power source, power cord, plug, control parts, and milling tools.
9. Before each use, make sure that no part is cracked or loose. Make sure to maintain correct conditions that can have an effect on the operation of the machine.
10. Keep the machine dry. Do not expose the machine to rain, snow, or frost.
11. Keep the work area well-ventilated, well-lit, clean, and free of obstacles.
12. Do not use near flammable materials or in explosive environments.
13. Use only tools specified in this Operator's Manual.
14. Do not use tools that are dull or damaged.
15. Make sure that the cutting inserts and the milling head are correctly attached. Remove wrenches from the work area before you connect the machine to the power source.
16. If the cutting edge of an insert is worn, rotate all inserts by 90°. If all edges are worn, install new inserts specified in this Operator's Manual.
17. Use eye protection, ear protection, respiratory protective devices, non-skid footwear, gloves, and protective clothing. Do not use loose clothing.
18. Do not touch chips or moving parts. Do not let anything catch in moving parts.
19. After each use, clean the machine and the milling head with a cotton cloth and no chemical agents. Do not remove chips with bare hands.
20. If you are not going to use the machine for an extended period, put anti-corrosion material on the steel parts.

21. Maintain the machine and install/remove parts and tools only after you unplug the machine from the power source.
22. Repair only in a service center appointed by the seller.
23. If the machine falls, is wet, or has any damage, stop the work and promptly send the machine to the service center for check and repair.

3. STARTUP AND OPERATION

3.1. Preparing

3.1.1. Adjusting the bevel angle and width

Unplug the machine from the power source. Start with setting the bevel width to zero. To do this, loosen the lock lever (Fig. 3), rotate the knob to set '0' on the bevel width scale, and tighten the lever.




Fig. 3. Initial setting the bevel width to zero

To set the required bevel angle (Fig. 4), use the 6 mm hex wrench to loosen two side screws. Rotate the guide set to get the required angle on the scale, and tighten the screws in this new position.




Fig. 4. Setting the bevel angle (45° is set on the drawing)

After you set the bevel angle, use the depth knob to adjust the bevel width. The width scale shows only a rough value because the bevel width varies with the angle. For example, for 10° the maximum width b (Fig. 1) is about 18 mm (11/16"), while the width scale shows about 9 mm (6/16"). Increasing the depth at this angle will distort the bevel. The maximum bevel width ($b = 21$ mm, 13/16") is for 45°. Find the required bevel width for the required angle in practice. To do this, gradually increase the penetration of the milling head into the workpiece.

3.1.2. Using the cutting fluid

Before you bevel stainless steel, put the supplied oil onto the workpiece as shown in Fig. 5.




Fig. 5. Preparing the edges for beveling stainless steel

3.2. Adapting for 150–300 mm pipes

To bevel pipes with diameters of 150–300 mm (6–12"), assemble the standard guide set in a different way. To do this, use the 6 mm hex wrench to remove two side screws (1, Fig. 6) and remove the guide set (2). Remove the set by 180° around the vertical axis (3), install again (4), and attach with the screws (1).




Fig. 6. Rotating and installing the guide set

Use the 12 mm flat wrench to prevent the turn of the T-nut and use the 8 mm hex wrench to remove the roller screw. Next, move the rollers from the hole (Fig. 7a) to the slot. Install the rollers as shown in Fig. 7b and put the T-nut into the slot.




Fig. 7. Moving the rollers from the hole to the slot

Loosen the depth lock lever (Fig. 8) and rotate the depth knob to set '0' on the bevel width scale. Then, move the rollers away from each other as far as possible.




Fig. 8. Initial setting the bevel width to zero and separating the rollers

Put the machine on a vertical pipe so that the surfaces of the guide set are in contact with the face and side of the pipe. Then, move the rollers symmetrically to make them contact the pipe (Fig. 8) and tighten them in this position. Set the required bevel angle and width as described before.




Fig. 9. Machine prepared for work on pipes with diameters of 150–300 mm (6–12")

3.3. Adapting for 300–600 mm pipes (option)

To bevel pipes with diameters of 300–600 mm (10–24"), assemble the guide set by using an optional guide. To do this, remove the guide set (1, 2, Fig. 6) and use the 4 mm hex wrench to remove the standard guide. Then, assemble the guide for 300–600 mm pipes (Fig. 10) and tighten with the screws. Install the rollers and adjust the required bevel angle and width as described before.




Fig. 10. Machine prepared for work on pipes with diameters 300–600 mm

3.4. Operating

After you set the bevel angle and width, connect the machine to a correctly grounded power source. Put the machine on the right so that the rollers are on the plate. Keep a gap between the milling head and the plate (Fig. 11).




Fig. 11. Machine correctly put on the workpiece

Set the power switch to 'I' and press the green START button to start the motor. Move the machine to the plate and bevel by moving the machine to the left. Constantly press the machine to the plate.

Beveling is done according to the counter-rotation. The rotation direction of the milling head is marked on the motor disk under the cover of the milling head.

The feed rate depends on the profile and composition of the workpiece.

Most steels capable of being welded can be beveled in one pass. However, make bevels wider than 12 mm (1/2") in at least two passes. This will require less effort and time than if you bevel in a single pass.

To get the maximum bevel width (21 mm, 13/16") in two passes, make the first bevel width of about 14 mm (9/16"). For three passes, make the first bevel width of about 12 mm (1/2") and the second of about 16 mm (5/8").

If an overload occurs because of, for example, too fast feed, the red overload lamp comes on. If you continue work in such a case, the motor stops. Then, move the machine away from the plate and set the power switch to 'O' to turn off the power. Next, wait until the overload lamp comes off, and turn on the power again.

You can work near the overload (when the red lamp flashes), but do not let the motor temperature increase more than 85°C (185°F). This can lead to damage of the motor windings. After each hour of work under full load, stop the motor for 10–15 minutes. Do not try to decrease the motor temperature by working without load. The motor will then get hotter than when working with load.

After the work is finished, press the STOP button to stop the motor. Then, set the power switch to 'O'. Use petroleum ether to clean oil from the workpiece.

Clean the machine with a cotton cloth and no chemical agents.

3.5. Replacing the cutting inserts

Unplug the machine from the power source. Remove the lever (1, Fig. 12), the indicator (2), and the milling head cover (3).




Fig. 12. Removing the milling head cover

Use the supplied T15P screwdriver to remove the fixing screw (Fig. 13), remove the insert, and clean the socket. Rotate the insert by 90° and install again or replace to a new one if all four edges are worn. To replace an insert from the internal ring, first remove the insert from the external ring.




Fig. 13. Replacing the cutting inserts

When you make bevels of low width, the cutting inserts wear only on one, inner corner. Then, the good thing is to change the inserts between the milling cutters (Fig. 7). This will extend the life of the inserts.




Fig. 14. Changing the cutting inserts between rings

3.6. Replacing the milling head

Remove the milling head cover as shown in Fig. 12. Use the 32 mm flat wrench to prevent the turn of the spindle (Fig. 15). Then, use the 8 mm hex wrench to remove the screw, and remove the milling head. The 32 mm flat wrench is not included in standard equipment.




Fig. 15. Replacing the milling head


4. SPARE AND WEARING PARTS

Name	Number
Milling head (including fixing screws and screwdriver; 10 inserts required)	GLW-0461-03-00-00-0
Cutting insert (sold 10 per box)	PLY-000282
Fixing screw for inserts	SRB-000311
T15P torx screwdriver for fixing screws	WKT-000005
Grease for screws (5 g, 0.17 oz)	SMR-000005
Oil for stainless steel (0.5 kg, 1.1 lbs)	OLJ-0505-09-00-00-0
Oil for stainless steel (1 kg, 2.2 lbs)	OLJ-0505-10-00-00-0
Oil for stainless steel (5 kg, 11 lbs)	OLJ-0505-11-00-00-0

5. ACCESSORIES

5.1. Guide for 300–600 mm pipes


Part number:
PRW-0505-03-00-00-0




5.2. Cutting tools

Part number	Part name
PLY-000591	Cutting insert (10 required, sold 10 per box)

6. WIRING DIAGRAM



7. EXPLODED DRAWINGS AND PARTS LIST




ITEM	PART NUMBER	DESCRIPTION	Qty
1	PWD-0461-17-00-00-0	POWER CORD – 230V	1
1	PWD-0461-17-00-00-1	POWER CORD – 115V	1
1	PWD-0461-17-00-00-2	POWER CORD – 230V (AU)	1
1	PWD-0461-17-00-00-3	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (INDIA)	1
1	PWD-0539-99-03-00-0	POWER CORD – 230V (JAPAN)	1
3	SLN-0505-01-00-00-2	MOTOR ASSY – 230V	1
3	SLN-0505-01-00-00-3	MOTOR ASSY – 115V	1
4	ZBI-0461-02-00-00-0	DRIVING RING	1
5	PKT-0461-04-00-00-0	KNOB	1
6	OSL-0461-05-00-00-0	MILLING HEAD COVER	1
7	PRW-0505-02-01-00-0	VERTICAL GUIDE	1
8	PRW-0505-02-02-00-0	HORIZONTAL GUIDE	1
9	OBS-0461-06-03-00-1	GUIDE HOLDER I	1
10	OBS-0461-06-04-00-1	GUIDE HOLDER II	1
11	OSK-0461-06-05-00-0	PIVOT	2
12	RLK-0505-02-03-00-0	ROLLER	4
13	RMK-0461-07-00-00-0	FRAME	1
14	RKJ-0461-08-00-00-0	FRONT HANDLE	1
15	MDL-0461-09-02-00-0	ELECTRONIC MODULE COMPLETE – 230V	1
15	MDL-0461-09-02-00-1	ELECTRONIC MODULE COMPLETE – 115V	1
15	MDL-0461-09-02-00-2	ELECTRONIC MODULE COMPLETE – 200V	1
16	PLY-0461-09-03-00-0	BOTTOM PLATE	1
17	PKR-0461-09-04-00-0	CONTROLLER HOUSING COVER	1
18	KON-0461-09-10-00-0	RED LAMP	1
19	KON-0461-09-11-00-0	YELLOW LAMP	1
20	WSK-0461-11-00-00-0	PENETRATION INDICATOR	1
21	LCZ-0461-12-00-00-0	LINK	1
22	USZ-0461-13-00-00-0	RUBBER SEAL	1
23	WBR-0461-14-00-00-0	DAMPER	4
24	GLW-0461-03-01-00-0	MILLING HEAD WITH BOLTS	1
28	NKR-000014	HEX. NUT M4	2
29	NKR-000032	NUT SHORT M4	2
30	NKR-000082	T-NUT	2
31	NIT-000010	ROUND HEAD RIVET 2x6	2
32	PDK-000021	ROUND WASHER 6,4	4
33	PDK-000022	ROUND WASHER 8.4	3
34	PDK-000026	ROUND WASHER 10.5	4
35	PDK-000175	SADDLE WASHER	4
36	PDK-000060	EXTERNAL TOOTH SPRING WASHER 4,3	6
37	PDK-000052	SPRING WASHER 10.2	2
38	PDK-000051	SPRING WASHER 8.2	8
39	PLY-000282	CUTTING INSERT	10
39**	PLY-000591	CUTTING INSERT	10
40	RKJ-000010	HANDLEVER	1
41	SRB-000311	MOUNTING BOLT	10
43	WKR-000183	SCREW M4x10 PHCRMS	4
44	KND-000114	CAPACITOR 30uF – 240V	1
44	KND-000115	CAPACITOR 80uF – 110V	1
45	NKR-000040	STRAIN RELIEF NUT	1
46	PDK-000043	SPRING WASHER 4.1	6

ITEM	PART NUMBER	DESCRIPTION	Qty
47	PDK-000046	SPRING WASHER 6.1	4
48	PNK-000013	POWER SWITCH	1
49	PRC-000007	MOTOR ON/OFF SWITCH	1
50	SRB-000075	HEX SOCKET BOLT M5x10	8
51	SRB-000124	HEX SOCKET BOLT M6x40	4
52	SRB-000141	HEX SOCKET BOLT M8x14	2
53	SRB-000156	HEX SOCKET BOLT M8x35	2
54	SRB-000046	HEX SOCKET BOLT M10x25	1
55	SRB-000309	HEX SOCKET BOLT M10x120	2
56	SRB-000148	HEX SOCKET BOLT M8x20	2
57	WZK-0461-09-07-00-0	STOP BUTTON WIRE SET	1
58	WZK-0461-09-08-00-0	CONTROLLER PLATE GROUNDING WIRE	1
59	WZK-0461-09-09-00-0	MOTOR GROUNDING WIRE	1
60	WKR-000446	CROSS RECESSED SCREW M4x20	2
61*	SKR-0461-15-00-00-0	METAL BOX	1
62*	KLC-000011	ALLEN KEY s=8	1
65*	KLC-0461-16-00-00-0	ALLEN KEY s=6 -mod.	1
66*	WKT-000005	TORX PLUS SCREWDRIVER T15Px100	1
67*	KLC-000032	FLAT KEY s=12	1
68*	KLC-000007	ALLEN KEY s=4	1
69*	SMR-000005	GREASE FOR SCREWS	1
70*	OLJ-0505-09-00-00-0	OIL FOR STEEL	0.5kg
71*	OLJ-0505-10-00-00-0	OIL FOR STEEL	1kg
72*	OLJ-0505-11-00-00-0	OIL FOR STEEL	5kg

* not shown in the drawing

** optional



SLN-0505-01-00-00-2		MOTOR ASSY - 230V	
SLN-0505-01-00-00-3		MOTOR ASSY - 115V	
ITEM	PART NUMBER	DESCRIPTION	Qty
1	TRC-0461-01-02-00-2	BEARING DISK N	1
2	TRC-000024	BEARING DISK P	1
3	KDL-000003	STATOR BODY - 230V	1
3	KDL-000004	STATOR BODY - 110V	1
4	WRN-000051	ROTOR	1
5	PDK-000195	CLEARANCE REMOVAL SPRING WASHER	1
6	OSL-000193	FAN COVER	1
7	WNT-000008	FAN	1
8	TBL-000032	4-TERMINAL PLATE	1
9	USZ-000030	SEAL no.4	1
10	WKR-000466	SELF-TAPPING SCREW M4x8	3
11	WPS-000015	PIN A6x6x32	1
12	LOZ-000139	BALL BEARING 6204 2Z C3	1
13	LOZ-000140	BALL BEARING 6206 2Z CM	1
14	SRB-000349	DRAWBOLT E/M5x168	3
15	WKR-000467	SELF-TAPPING SCREW M4x12	1

8. DECLARATION OF CONFORMITY

Declaration of Conformity

***PROMOTECH sp. z o.o.
ul. Elewatorska 23/1
15-620 Białystok
Poland***

We declare with full responsibility that product:

BM-21S Beveling Machine

which the declaration applies to is in accordance with the following standard:

- EN 50144-1

and satisfies regulations of the guidelines: 2006/95/EC and 2006/42/EC.

Person authorized to compile the technical file:

Marek Siergiej, ul. Elewatorska 23/1, 15-620 Białystok, Poland



Białystok, 8 November 2011

Marek Siergiej
CEO

9. WARRANTY CARD

WARRANTY CARD No.....

..... in the name of Manufacturer warrants the BM-21S Beveling Machine to be free of defects in material and workmanship under normal use for a period of 12 months from the date of sale.

This warranty does not cover cutting inserts as well as damage or wear that arise from misuse, accident, tempering or any other causes not related to defects in workmanship or material.

Serial number

Date of sale

Signature of seller.....

1.10 / 30 April 2019

WE RESERVE THE RIGHT TO MAKE CHANGES IN THIS MANUAL WITHOUT NOTICE