




The tools of innovation.

OPERATOR'S MANUAL

DRILLING MACHINE WITH ELECTROMAGNETIC BASE

D2 PRO



801 W. Mineral Ave. Suite 103 Littleton, CO 80120

303-690-9146, FAX 303-690-9172

www.steelmax.com sales@steelmax.com

Contents

1. GENERAL INFORMATION	3
1.1. Application.....	3
1.2. Technical data	3
1.3. Equipment included.....	4
1.4. Dimensions.....	5
1.5. Design.....	6
2. SAFETY PRECAUTIONS.....	7
3. SYMBOLS.....	9
4. STARTUP AND OPERATION	10
4.1. Installing the handles.....	10
4.2. Installing the tools.....	11
4.3. Installing and removing the drilling chuck (option).....	12
4.4. Installing and removing the cooling system	13
4.5. Monitoring system of the clamping force.....	14
4.6. Preparing.....	14
4.7. Drilling	16
4.8. Adjusting the gibs	18
4.9. Replacing the brushes.....	19
5. ACCESSORIES	20
5.1. Pressure cooling system.....	20
5.2. Drilling chuck 1/2" 20 UNF x 1.5-13 mm	20
5.3. Drilling chuck 1/2" 20 UNF x 3-16 mm	21
5.4. Adapter 3/4" x 1/2" 20 UNF	21
5.5. Pipe attachment DMP 251.....	21
5.6. Pipe attachment DMP 501.....	22
5.7. Vacuum pad	23
5.8. Ejector	24
6. EXPLODED DRAWINGS AND PARTS	25
7. DECLARATION OF CONFORMITY	34
8. ENVIRONMENTAL PROTECTION	35
9. WARRANTY CARD.....	36

1. GENERAL INFORMATION

1.1. Application

The D2 PRO is a drilling machine designed to drill holes of diameters of up to 2 11/64" (55 mm) by using annular cutters. The machine can also drill holes of diameters of up to 5/8" (16 mm) by using twist drill bits. It also allows for machining holes of diameters of up to 2" (50 mm) by using countersinks.


The electromagnetic base clamps the machine to ferromagnetic surfaces. This makes sure that the operator is safe and the machine works correctly. A safety strap protects the machine from falling in case of a clamping loss.

Accessories allow you to drill in pipes and clamp the machine to flat non-ferromagnetic surfaces.

1.2. Technical data


Voltage	1~ 220-240 V, 50-60 Hz 1~ 110-120 V, 50-60 Hz
Power	1100 W
Spindle shank	3/4" (19 mm) Weldon
Tool holder	3/4" (19 mm) Weldon
Maximum drilling diameter with a TCT annular cutter	2 11/64" (55 mm)
Maximum drilling diameter with a HSS annular cutter	2" (50 mm)
Maximum drilling diameter with a twist drill bit	5/8" (16 mm)
Maximum diameter of a hole to be machined with a countersink	2" (19 mm)
Maximum drilling depth	3" (75 mm)
Clamping force (surface with the thickness of 25 mm and roughness $R_a = 1.25$)	9900 N
Electromagnetic base dimensions	3 5/16" × 6 39/64" × 1 41/64" 84 mm × 168 mm × 41.5 mm
Stroke	6 19/64" (160 mm)
Rotational speed with load	200 rpm 400 rpm
Minimum workpiece thickness	15/64" (6 mm)
Protection class	I
Protection level	IP 20
Noise level	More than 70 dB
Required ambient temperature	32-104°F (0-40°C)
Weight	33.1 lbs (15 kg)

1.3. Equipment included




1	Drilling machine	1 unit
2	Plastic box	1 unit
3	Handle	3 units
4	Safety strap	1 unit
5	Cooling system	1 unit
6	2.5 mm hex wrench	1 unit
7	5 mm hex wrench	1 unit
8	5 mm hex wrench with a handle	1 unit
9	8 mm combination wrench	1 unit
-	Operator's manual	1 unit

1.4. Dimensions



1.5. Design



2. SAFETY PRECAUTIONS

1. Before use, read this operator's manual and complete a training in occupational safety and health.
2. Use only in applications specified in this operator's manual.
3. Make sure that the machine has all parts and they are genuine and not damaged.
4. Make sure that the specifications of the power source are the same as those specified on the rating plate.
5. Connect the machine to a correctly grounded power source. Protect the power source with a 16 A fuse for 230 V or a 32 A fuse for 115 V. If you are going to work on building sites, supply the machine through an isolation transformer with class II protection only.
6. Set the MAGNET switch to 'O' before you move the machine. Use carrying handle to move the machine.
7. Do not carry the machine by the power cord and do not pull the cord. This can cause damage and electric shock.
8. Keep untrained bystanders away from the machine.
9. Before each use, ensure the correct condition of the machine, power source, power cord, plug, control panel, and tools.
10. Before each use, make sure that no part is cracked or loose. Make sure to maintain correct conditions that can have an effect on the operation of the machine.
11. Keep the machine dry. Do not expose the machine to rain, snow, or frost.
12. Do not stay below the machine that is put at heights.
13. Keep the work area well-lit, clean, and free of obstacles.
14. Make sure that the tool is correctly attached. Remove wrenches from the work area before you connect the machine to the power source.
15. Do not use tools that are dull or damaged.
16. Unplug the power cord before you install and remove tools. Use protective gloves to install and remove tools.
17. Unplug the power cord before you manually turn the spindle.
18. Use annular cutters without the pilot pin only when you drill incomplete through holes.
19. Do not drill/machine holes whose diameter or depth differ from those specified in the technical data.
20. Do not use in explosive environments or near flammable materials.

21. Do not use on surfaces that are rough, not flat, not rigid, or have rust, paint, chips, or dirt.
22. Do not use if the gibs are adjusted incorrectly.
23. Do not use if there is no grease on the gibs.
24. Do not use the gear switch if the motor is on.
25. Use the safety strap to attach the machine to a stable structure. Put the strap through the hole in the machine body. In the horizontal position, attach the strap to the carrying handle. Do not put the strap into the buckle from the front.
26. Use eye and ear protection and protective clothing. The clothing must not be loose.
27. We do not recommend work on workpieces thinner than 15/64" (6 mm). The clamping force depends on the workpiece thickness and is much lower for thin plates.
28. Each time before you put the machine on the workpiece, rub the workpiece with coarse-grained sandpaper. Make sure that the full bottom of the base touches the workpiece.
29. Do not touch chips or moving parts. Do not let anything catch in moving parts.
30. After use, clean the machine and the tool. Do not remove chips with bare hands.
31. Unplug the power cord before you do maintenance or install/remove parts.
32. Repair only in a service center appointed by the seller.
33. If the machine falls, is wet, or has any damage, stop the work and immediately send the machine to the service center for check and repair.
34. Do not leave the machine when it operates.
35. If you are not going to use the machine, remove the tool from the holder. Then, remove the machine from the work area and keep it in a safe and dry place.
36. If you are not going to use the machine for an extended period, put anti-corrosion material on the steel parts.

3. SYMBOLS

Before using the machine, read the description of the following symbols (Tab. 1).



Wear eye protection



Wear ear protection



Refer to instruction manual



Warning against electric voltage

Tab. 1. Description of symbols


4. STARTUP AND OPERATION

4.1. Installing the handles

Attach the handles to the feed shaft. You can install the shaft so that the handles are on the opposite side of the machine. To do this, continue in the sequence that follows.




Make sure that the shaft is engaged with the rack (4).



4.2. Installing the tools

Unplug the power cord and lift the chip guard (1). Turn the handles to the right (2) to lift the motor. Use gloves to put the correct pilot pin into the annular cutter (3). Use a dry cloth to clean the spindle and the cutter. Put the cutter (twist drill bit or countersink) into the spindle (4) so that the flat surfaces (5) align with the screws (6). Use the 5 mm hex wrench to tighten the screws.


To remove the tool, loosen the screws (6) with the 5 mm hex wrench.



4.3. Installing and removing the drilling chuck (option)

Unplug the power cord and lift the chip guard (1). Turn the handles to the right (2) to lift the motor. Attach the adapter to the drilling chuck (3). Use a dry cloth to clean the spindle and the chuck. Then, put the chuck into the spindle (4) so that the flat surfaces (5) align with the screws (6). Use the 5 mm hex wrench to tighten the screws. Put the twist drill bit into the chuck (7).


To remove the chuck, loosen the screws (6) with the 5 mm hex wrench.



4.4. Installing and removing the cooling system

Put the bottle on the screws (1). Attach the hose to the fitting (2).

To remove the bottle, continue in reverse sequence.



4.5. Monitoring system of the clamping force

The drilling machine has a system that monitors the clamping force of the electromagnetic base. The force will be lower if there is rust, paint, chips, or dirt. The force will be lower also if the surface is thin, rough, not flat, not rigid, the voltage is lower than required, or the bottom of the base is worn.

If the clamping force is too low, the system will not allow the machine to operate. Then, after you release the green MOTOR button, the motor stops. This happens on a surface thinner than 13/64" (5 mm). The clamping force is then only about 25% of the force that you can get on a flat plate that is 1" (25 mm) thick. To drill on thin plates then, press and hold the green MOTOR button.

4.6. Preparing

Before use, clean steel parts, including the spindle, from anti-corrosion material used to preserve the machine for storage and transport.

Attach the handles to the feed shaft. You can install the shaft so that the handles are on the opposite side of the machine.


Apply a thin layer of grease to the gibs.

Select the tool that matches the required hole diameter. Use a dry cloth to clean the spindle and the tool. Then, install the tool as described before.

Put the machine on a flat ferromagnetic surface with the thickness of at least 15/64" (6 mm). Make sure that there is no rust, paint, chips, or dirt. They decrease the clamping force. The force will be lower also if the surface is thin, rough, not flat, not rigid, the voltage is lower than required, or the bottom of the base is worn.

Connect the machine to the power source. Set the MAGNET switch to 'I' to turn on the clamping. Some types of steel (non-ferromagnetic) do not conduct magnetic flux so the machine cannot clamp onto them.

Use the safety strap to prevent fall and injury if the machine loses the clamping. Attach the machine to a stable structure by putting the strap through the hole in the machine body. In the horizontal position, attach the strap to the carrying handle. Make sure that the strap is tight and not twisted. If the machine comes loose from the workpiece and hangs on the strap, replace the strap. Do not put the strap into the buckle from the front.









Turn the handles to the left to put the tool tip above the workpiece.

For vertical drilling with an annular cutter, install the cooling system and fill it with coolant. Do not use only water as the coolant. But you can mix water and drilling oil. Then, make sure that the cooling system works correctly. To do this, lightly loosen the bottle cap and use the lever to open the valve. Then, turn the handles to the left to apply a light pressure on the pilot pin. The coolant should fill the system and start flowing from the cutter.

The cooling system works by gravity. Thus, in the horizontal position, turn the bottle. In the inverted position, use coolants under pressure or in the form of spray or paste.

4.7. Drilling

Set the speed based on the table that follows.

Tool	Hole diameter		Rotational speed* [rpm]	Gear switch setting
	[mm]	[in]		
HSS annular cutter	12-25	15/32-1	400	
	26-50	1 1/32-2	200	
TCT annular cutter	12-28	15/32-1 7/64	400	
	29-50	1 9/64-2	200	
Twist drill bit	1.5-16	1/16-5/8	400	
	—	—	200	

* For a sharp tool and mild steel of strength $R_m < 500 \text{ N/mm}^2$ (70,000 psi), such as St0 (S185), St3S (S235JR), or St4W (S275JO).


Steel of strength $R_m \geq 500 \text{ N/mm}^2$ (70,000 psi), such as St5 (E295), 18G2A (S355N), or 45 (C45), requires lower speeds. If the speed is too high or too low for the workpiece strength and the type/diameter of the tool, the tool will wear faster or be unable to drill the hole.

Press the green MOTOR button to start the motor. Turn the handles to the left to put the tool into the workpiece.



When the annular cutter goes through the workpiece, the slug core is pushed out with a large force.

When you use an annular cutter, drill only through holes. For incomplete through holes do not use the pilot pin.



Keep the machine in the same position until the hole is made.

If you are going to drill holes deeper than 2" (50 mm), retract the tool from the workpiece as often as possible. This allows chips to be removed from the hole. If the grooves of the tool are clogged, turn off the motor and use a brush to clean them.

After you get to the depth of 1 37/64" (40 mm), retract the tool from the workpiece as often as possible. Then, manually apply the coolant from the bottle into the drilling area.

After the hole is made, retract the tool from the workpiece, and press the red MOTOR button to turn off the motor. Before you move the machine, set the MAGNET switch to 'O' to turn off the base.


After the work is finished and the motor turned off, set the gear switch to the opposite position. Then, turn on the motor and let it operate for a while with no load to improve lubrication. Next, turn off the motor and the base, and then unplug the power cord. Clean the machine and the tool, and then remove the machine from the work area.

Tighten the bottle cap, close the valve, and then press the pilot pin to remove the coolant that remains in the cooling system. Before you put the machine into the box, remove the bottle, and use gloves to remove the tool from the holder.

4.8. Adjusting the gibs

Every 50 work hours, make sure that the gibs are correctly adjusted. To do this, move the motor up and down and make sure that it moves smoothly.


To adjust the gibs, apply a thin layer of grease on them. Then, use the 8 mm combination wrench, the 2.5 mm hex wrench, and the 5 mm hex wrench to loosen the nuts and screws (1). Put the motor so that the slider is in the center of the gibs (2). Then, lightly tighten the screws (3) so that they touch the gib. Move the motor up and down and adjust the screws (3) so that the travel is smooth. Next, tighten the screws (4) and then tighten the nuts (5).



4.9. Replacing the brushes

Every 100 work hours, check the condition of the brushes. To do this, unplug the power cord and remove the cover (1). Lift the spring (2) and remove the brush. If the brush is shorter than 13/64" (5 mm), replace the two brushes with new ones.

Install in reverse sequence. Then, let the motor operate with no load for 20 minutes.




5. ACCESSORIES

5.1. Pressure cooling system


Capacity of 2 liters.

Part number:
UKL-0440-16-00-00-0





5.2. Drilling chuck 1/2" 20 UNF x 1.5-13 mm

Part number:
UCW-000059




5.3. Drilling chuck 1/2" 20 UNF x 3-16 mm

Part number:
UCW-000061




5.4. Adapter 3/4" x 1/2" 20 UNF

Part number:
TRZ-000027



5.5. Pipe attachment DMP 251


For pipes with diameters of 3-10" (80-250 mm).



Part number:
PDS-0110-03-00-01-0

5.6. Pipe attachment DMP 501

For pipes with diameters of 6-20" (150-500 mm).




Part number:
PDS-0111-03-00-01-0


5.7. Vacuum pad

Allows you to clamp the machine to flat non-ferromagnetic surfaces.

Part number (vacuum pad, supply hose):
PDS-0587-00-00-00-0




Part number (vacuum pump with safety reservoir):
AGR-0541-01-20-00-0




5.8. Ejector

Allows the vacuum pad to be clamped to the surface by using compressed air source.

Part number:
ZSP-0587-11-00-00-0




6. EXPLODED DRAWINGS AND PARTS



ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	SKR-000028	PLASTIC BOX	1
2	DZW-0212-12-00-00-1	SPOKE HANDLE ASSY	3
3	KLC-000005	2,5 HEX WRENCH	1
4	KLC-0565-08-00-00-0	5 HEX WRENCH	1
5	KLC-000003	8 COMBINATION WRENCH	1
6	KLC-000037	5 MM HEX WRENCH WITH HANDLE	1
7	PAS-000008	SAFETY STRAP	1
8	UKL-0716-04-00-00-0	COOLING SYSTEM	1

*not shown in the drawing




ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	NPD-0716-02-00-00-0	MOTOR ASSY – 230V	1
1	NPD-0716-02-00-00-1	MOTOR ASSY – 115V	
2	PWD-0684-03-02-00-1	MOTOR WIRE ASSY	1
3	WKR-000395	HEX SOCKET ROUND HEAD SCREW WITH FLANGE	2
4	PDK-000151	NYLON WASHER 8,1x14x3	4
5	SPR-000030	SPRING 1x10x17.5	2
6	TLJ-0399-06-00-00-0	BOTTOM SLEEVE	2
7	WKR-000415	HEX SOCKET ROUND HEAD SCREW WITH FLANGE 3,5x13	8
8	PDK-000161	EXTERNAL TOOTH LOCK WASHER 3.7	8
9	SCN-0716-06-00-00-0	BODY COVER	1
10	SRB-000304	HEX SOCKET HEAD CAP SCREW M6x20	8
11	PDK-000136	ROUND WASHER 6,4	8
12	LST-0331-01-05-00-0	GIB	1
13	LST-0331-01-04-00-0	ADJUSTABLE GIB	1
14	PDK-00004	SPRING WASHER 6.1	4
15	SRB-000117	HEX SOCKET HEAD CAP SCREW 6x25 Zn	2
16	PDS-0716-03-00-00-0	ELECTROMAGNETIC BASE ASSY	1
17	WZK-0242-04-00-00-0	REED WIRES SET	1
18	FLT-0257-04-12-00-0	INTERFERENCE ELIMINATOR	1
19	STR-0257-04-03-00-2	MODULE - 230V	1
19	STR-0257-04-03-00-3	MODULE - 115V	1

This document is protected by copyrights.


Copying, using, or distributing without permission of Steelmax Tools is prohibited.

ITEM	PART NUMBER	DESCRIPTION	Q-TY
20	MSK-0716-05-01-00-0	PANEL PLATE	1
21	PNK-000013	MAGNET SWITCH	1
22	WLC-000007	START-STOP SWITCH - 230V	1
22	WLC-000005	START-STOP SWITCH - 115V	1
23	WLK-0140-04-01-00-1	PINION SHAFT	1
24	PRS-000019	EXTERNAL RETAINING RING 28z	1
25	SZN-0212-10-02-00-2	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (EU)	1
26	SZN-0075-00-51-00-5	POWER CORD 120V 3x2.08 WITH STRAIN RELIEF ASSY (US)	1
26	SZN-0212-10-02-00-5	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (AU)	1
26	DLW-000007	CABLE GLAND WITH STRAIN RELIEF PG11	1
27	WKR-000434	CROSS RECESSED COUNTERSUNK HEAD SCREW M4x20	1
28	PDK-000060	EXTERNAL TOOTH LOCK WASHER 4.3	1
29	NKR-000013	HEX NUT M4	1
30	KRP-0684-01-01-01-1	DRILL BODY ASSY	1
31	OSL-0684-06-00-00-0	GUARD	1
32	SRB-000115	HEX SOCKET HEAD CAP SCREW 6x25	2
33	WKR-000077	HEX SOCKET SET SCREW WITH FLAT POINT M5X16	3
34	NKR-000016	HEX NUT M5	3
35	PNL-0741-03-00-00-0	CONTROL PANEL ASSY. 230V	1
35	PNL-0741-03-00-00-1	CONTROL PANEL ASSY. 115V	1



ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	WKR-000180	CROSS RECESSED PAN HEAD SCREW M3 x 5	2
2	TBL-0202-00-30-00-0	GEAR LABEL	1
3	SRB-000090	HEX SOCKET HEAD CAP SCREW M5x35	1
4	PDK-000045	SPRING WASHER 5,1	1
5	TLJ-0171-00-22-00-0	SWITCH SLEEVE	1
6	SPR-0171-00-23-00-0	SPRING DOWEL PIN 3x14	1
7	DZW-0171-00-24-00-0	SHIFT LEVER	1
8	WLK-0202-00-16-00-1	SHIFT PIN SHORT	1
9	WDL-0211-00-28-00-1	SHIFT FORK	1
10	SLN-0684-03-00-00-0	ENGINE ASSY	1
11	PRS-000017	EXTERNAL RETAINING RING 25z	1
12	WPS-0211-00-13-00-1	KEY 6x6x15	1
13	KOL-0741-01-01-00-0	GEAR	1
14	PDK-000264	DISTANCE WASHER 25x35x1	1
15	LOZ-000028	BALL BEARING 25x47x12	1
16	LOZ-000006	NEEDLE BEARING 8x12x10	2
17	KOL-0211-00-08-00-0	GEAR	1
18	WPS-0211-00-14-00-1	KEY 3x3x36	1
19	WLK-0741-02-01-00-0	GEAR SHAFT	1
20	PDK-0211-00-15-00-0	WASHER 10,1x15x1	1
21	LOZ-000009	NEEDLE BEARING 10x16x10	1
22	WKR-000196	HEX SOCKET ROUND HEAD SCREW WITH FLANGE M5x12	2
23	KLK-000034	DOWEL PIN 4x14	1
24	LOZ-000055	BALL BEARING 8x22x7	1
25	KOL-0211-00-06-00-0	HELICAL INPUT GEAR	1
26	WPS-0211-00-17-00-1	KEY 3x3,7	1
27	WLK-0211-00-07-00-0	GEAR SHAFT	1
28	PDK-0211-00-16-00-0	WASHER 8,1x13x1	1
29	KNC-0234-00-10-00-0	HOSE FITTING	1
30	SRB-000304	HEX SOCKET LOW HEAD CAP SCREW M6x20	4
31	SRB-000114	HEX SOCKET HEAD CAP SCREW M6x20	2
32	PDK-000046	SPRING WASHER 6,1	6
33	LST-0129-00-04-00-1	GEAR RACK	1
34	PLY-0716-02-01-02-0	SLIDE PLATE	1
35	KRP-0716-02-01-01-1	GEARBOX BODY	1
36	PRS-000399	SEAL28x38x7	2
37	PRS-000398	EXTERNAL RETAINING RING 38w	1
38	PRS-000021	EXTERNAL RETAINING RING 30z	1
39	LOZ-000049	BALL BEARING30x55x13	1
40	WRZ-0716-02-02-00-0	SPINDLE WELDONE ASSY	1
41	WRZ-0716-02-02-01-0	SPINDLE WELDONE	1
42	WKR-000032	HEX SOCKET SET SCREW WITH FLAT POINT M10x10	2
43	SPR-0220-00-03-00-1	SPRING 1,25x8x158,5x42,5	1
44	WYP-0203-06-02-00-0	PLUNGER	1
45	USZ-0220-00-04-00-0	SEAL fi9,4x3	1
46	PDK-0220-00-05-00-0	WASHER 19x10x1,5	1
47	PRS-000009	EXTERNAL RETAINING RING 19W	1
48	WKR-000514	CROSS RECESSED OVAL PAN HEAD SCREW FOR PLASTIC 4x25	1
49	PRP-000005	CABLE GLAND PG9	2


ITEM	PART NUMBER	DESCRIPTION	Q-TY
50	RDC-000016	THREAD REDUCTION PG9/PG7	1
51	USZ-0279-02-07-00-0	SEAL	1
52	PSZ-0291-02-05-00-0	WIRE COVER	1
53	WKR-000186	CROSS RECESSED PAN HEAD SCREW M4x14	1
54	PDK-000017	ROUND WASHER 5,3	4
55	KLK-000005	SPRING DOWEL PIN 3x14	1
56	SRB-000083	HEX SOCKET HEAD CAP SCREW M5x16	4
57	PDK-000045	SPRING WASHER 5,1	4
	SMR-000009	GREASE	0,39kg



ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	WKR-000423	CROSS RECESSED PAN HEAD SELF-TAPPING SCREW 4,8x38	4
2	PKR-0684-03-01-00-1	GEARBOX COVER	1
3	KNC-0300-03-02-00-0	ROTOR END	1
4	LOZ-000086	BALL BEARING 12x32x10	1
5	PRS-000022	EXTERNAL RETAINING RING 32w	1
6	WRN-0684-99-02-00-0	ROTOR ASSY 230V	1
7	WRN-0684-99-02-00-1	ROTOR ASSY 120V	1
8	LOZ-000095	BALL BEARING 7x22x7	1
9	OBD-0684-99-01-00-0	STATOR HOUSING ASSY – 230V	1
9	OBD-0684-99-01-00-1	STATOR HOUSING ASSY – 115V	1
10	WKL-000008	BEARING INSERT 22x9	1

ITEM	PART NUMBER	DESCRIPTION	Q-TY
11	WKR-000357	PAN HEAD SHEET METAL SCREW 4.8x85	2
11	PON-000001	STATOR GUARD	1
12	STN-000041	STATOR 230V	1
13	STN-000042	STATOR 120V	1
14	WKR-000358	SCREW TW4X13 kb/1	2
15	PKR-000015	BRUSH COVER	2
15	WKR-000360	SCREW M4x8	2
16	PDK-000225	SPRING WASHER 4,2x0,5	2
17	SCZ-000009	BRUSH 6.4x12.5x19	2
18	SCT-000012	BRUSH HOLDER 6.4x12.5 ASSY	2
19	PLY-000066	PLATE 8x13	2
20	WKR-000359	SCREW Ph-TZ 3.5x13	2
21	SPR-000020	SPRING 6x0,25	2
22	OBD-0279-02-03-09-0	MOTOR COVER	1
23	WKR-000081	SELF-TAPPING SCREW 4,8x19	4
24	PKR-0279-02-06-00-0	STATOR COVER	1

WIRING DIAGRAM



This document is protected by copyrights.

Copying, using, or distributing without permission of Steelmax Tools is prohibited.

7. DECLARATION OF CONFORMITY

Declaration of Conformity

PROMOTECH sp. z o.o.
ul. Elewatorska 23/1
15-620 Białystok
Poland

We declare with full responsibility that:

D2 Pro Drilling Machine with Electromagnetic Base

is manufactured in accordance with the following standards:

- EN ISO 12100:2010
- EN 62841-1:2015
- EN 55014-1:2017

and satisfies the regulations of the guidelines: 2014/30/EU, 2006/42/EC, 2011/65/EU.

Person authorized to compile the technical file:

Wiktor Marek Siergiej, ul. Elewatorska 23/1, 15-620 Białystok, Poland



Białystok, 15 February 2022

Wiktor Marek Siergiej
CEO

8. ENVIRONMENTAL PROTECTION



In accordance with the European Directive 2012/19/EU, this device is marked with the symbol of the crossed-out waste bin. This marking means that the equipment must not be disposed of with other household waste after the service life. The user must return the product to a collection point for used electrical and electronic equipment. The collectors of used equipment, including local collection points, shops and municipal units create an appropriate system for returning such equipment. Correct handling of used electrical and electronic equipment helps in avoiding damage to health and the environment, which may result from the presence of dangerous components and incorrect storage and processing of such equipment.

9. WARRANTY CARD

WARRANTY CARD No.....

..... in the name of Manufacturer warrants the D2 Pro Drilling Machine with Electromagnetic Base to be free of defects in material and workmanship under normal use for a period of 12 months from the date of sale.

This warranty does not cover tools as well as damage or wear that arise from misuse, accident, tampering or any other causes not related to defects in workmanship or material.

Serial number

Date of sale

Signature and stamp of the seller

0.01 / 08 April 2024

WE RESERVE THE RIGHT TO MAKE CHANGES IN THIS MANUAL WITHOUT NOTICE